


4G Camera Migration & Connection Guide

Move Your Camera to iCSee

App migration guide



Use iCSee for device setup and management

Follow the connection steps in this guide

Models: C0074

💡 **Tip:** You do not need to physically unmount your camera! Simply open "INSEECam", go to Device Settings, and tap '**Remove Device**' to reset it online.

Applicable Models

Match your camera model below, then follow the 4G QR code setup steps.



C0074

Before You Start

- **Install iCSee, open the app, and sign in or create an account.**
- **Fully charge the camera for 6–12 hours before first use.**
- **Insert the included 4G SIM card.** Do not replace it with a third-party SIM card.
- **Grant Camera, Cellular Data, and Local Network permissions when prompted.**
- **Power on the camera in an area with stable 4G coverage.** If previously connected, use “Remove Device” in INSEECam to reset it online.

Download iCSee & Create an Account

- ① Scan the QR code below, or search for “iCSee” in Google Play and App Store. Then download and install the APP.

Download iCSee

Scan the QR code for your phone



Android

Google Play



iPhone / iPad

Apple App Store

Or search for “iCSee” in the app store.

Important: These QR codes download iCSee. Do not scan an old INSEECam app download QR code.

- ② Select “Login to your account” or “Sign up” in the red box, and enter your email address to complete the registration.

17:56

5G 81



Register

United States



Please enter email

Please enter password





- Password must be 8–64 characters
- Contains uppercase letters, lowercase letters, numbers

Next


Set Up The Camera

① Power on the camera. Wait for the device to start and connect to the 4G network. If previously connected, remove it from INSEECam or reset it.

② Tap the “+” and choose “Add Device”.



③ Tap “4G Camera”. Wait for the “Network connection successful” prompt, select “I heard the prompt”, and tap Next.



Device Setup

Power on the device. Click "Next" when it announces "Network connection successful".


☐ I heard the prompt

Next

Note:

If no prompt is heard, check the included SIM card, battery level, and local 4G coverage.

④ Scan the device QR code printed on the camera body or product label.



Important:

Scan the device QR code, not the iCSee download QR code.

⑤ Check the device type and serial number, then tap Add Device. When prompted, tap Save to keep the device QR code for future re-adding or sharing.

App Store

< Add Camera

Type of device

Battery Camera

Device serial number

EXAMPLE SERIAL NUMBER

Add Device

Device added

Whether to save the QR code of this device for easy future addition or sharing.

EXAMPLE C0074

EXAMPLE SN

Cancel Save(8s)

Top-Up 4G Data

1) After the camera shows Online, If you need to recharge your data plan, please open this website link.

<https://h5.miotclub.com/#/card>

Google Suggestions

Q <https://h5.miotclub.com/#/card>

On This Page (no matches)

Find "https://h5.miotclub.com/#/card"



Scan the QR code
to charge

1


<https://h5.miotclub.com/#/card>

The recharge website should open in your phone browser.

use the website link <https://h5.miotclub.com/#/card>

Or You can also scan the QR code to access the recharge page.

2) Open the recharge website, enter the ICCID printed on the included SIM card , and tap Search.



Metrix Aero Core

SIM card ICCID number ²

INPUT ICCID

Tips : Enter 19 or 20 digit SIM card ICCID number in the input box, The last digit can be omitted

How to find ICCID? ³

Search


Email login

Contact us via email: info@musmoon.com

Important:


Enter your ICCID without spaces. Use the ICCID on the included SIM card

3) Check Remaining Data, Current Plan, and validity. Select a data plan and complete payment on the website.



Data Plans

Plans auto-rotate after expiration. See full queue in Plans tab below. [↗](#)



Troubleshooting

- **Device QR Code Not Found**

Clean the label, improve lighting, and center the device QR code inside the scan frame.

- **4G Network Not Available**

Check that the included SIM card is inserted, the battery is charged, and 4G coverage is available.

- **Camera Shows Offline**

Verify the data plan is active and has remaining data, then restart the camera.

- **Recharge Website / Plan Not Updated**

Open the recharge website again, enter the same ICCID, and refresh the plan status. Restart the camera after the plan becomes active.

Support

support@inseecam.net

WhatsApp: +86 13318775092